



HANDBOOK

QuickGene DNA whole blood kit S (DB-S)

For extraction of genomic DNA from whole blood

Ver.4.0

Contents

1. Introduction	4
2. Kit components and Storage Conditions	4
2-1. Kit Components (96 Preps).....	4
2-2. Storage Conditions	4
3. Other Required Materials, Not Supplied in This Kit.....	5
4. Safety Warnings	6
5. Precautions.....	7
6. Quality Control.....	8
7. Product Description	8
8. Protocol	9
8-1. Preparations of Reagents	9
8-2. Lysate Preparation Protocol.....	11
8-3. Extraction Protocol with QG-810.....	14
8-4. Extraction Protocol with QG-Mini480.....	17
9. Troubleshooting	21
10. Ordering Information	26
Appendix 1 Setting of QG-810 Parameter.....	27

Warning

For research use only.

Not recommended or intended for diagnostic or clinical application for humans or animals.

1. Introduction

This is a reagent kit for the extraction process of QuickGene-810 (Hereinafter QG-810) or QuickGene-Mini480 (Hereinafter QG-Mini480). When using this kit with QG-810 or QG-Mini480, high quality and high yield genomic DNA can be extracted and also purified from 200 µl of whole blood. The key features of this kit are described below;

- DNA from whole blood samples can be simultaneously extracted in following time.
QG-810: about 6 min for 8 sets of whole blood samples
QG-Mini480: about 45 min for 48 sets of whole blood samples
- The purified, high quality genomic DNA is suitable for PCR, restriction enzyme digestion, NGS analysis and other applications

Please be sure to read the User's Guide of QuickGene carefully before using this kit.

2. Kit components and Storage Conditions

2-1. Kit Components (96 Preps)

Confirm that following contents is packed.

There are 96 reactions of genomic DNA isolation reagent and consumables.

<input type="checkbox"/> Protease	EDB	1 vial
<input type="checkbox"/> Lysis Buffer	LDB	30ml
<input type="checkbox"/> Wash Buffer	WDB	160ml
<input type="checkbox"/> Elution Buffer	CDB	100ml
<input type="checkbox"/> Cartridges	CA	96pcs
<input type="checkbox"/> Collection Tubes	CT	96pcs
<input type="checkbox"/> Caps	CAP	96pcs
<input type="checkbox"/> Waste Tubes	WT	96pcs

2-2. Storage Conditions

All reagents are stable at room temperature (15-28°C) until expiring date indicated at outer box. Reconstituted EDB is stable for 2 months when stored at 4°C. Storage at –20°C will prolong the life of EDB, but repeated freezing and thawing should be avoided. Dividing the solution into aliquots and storage at –20°C is recommended.

3. Other Required Materials, Not Supplied in This Kit

[1] Reagents

- >99% Ethanol (for Molecular Biology / Purity: $\geq 99.5\%$ (GC))
- Nuclease-free water (for dissolving EDB)

[2] Equipment

- QG-810 or Mini480
- Centrifuge tube* (Large / Small sets)
- Micropipettes and tips
- 1.5ml microtubes
- Tube stand
- Tube mixer (maximum speed at 2,500 rpm or more)
- Benchtop microcentrifuge
- Heat block or water bath (at 56°C)

* Centrifuge tubes are used with QG-810 as containers for WDB (>99% ethanol added) and CDB. They are unnecessary when QG-Mini480 is used.

Recommendation product of centrifuge tubes are following Table 1.
Use centrifuge tubes according to the number of Cartridges to use.

Table1 Recommended centrifuge tubes (In case of QG-810)

Size of Buffer Stand (Centrifuge Tube Holder)	The number of Cartridges	Type of centrifuge tube	Product name (Examples)
Standard	~ 16	Large centrifuge tube (for WDB)	BD Falcon™50 ml conical tube
		Small centrifuge tube (for CDB)	BD Falcon™15 ml conical tube
Large	~ 72	Large centrifuge tube (for WDB)	BD Falcon™175 ml conical tube
		Small centrifuge tube (CDB)	BD Falcon™50 ml conical tube

4. Safety Warnings

All reagents and items should be considered chemically and biologically hazardous. Wearing a laboratory coat, disposable gloves and safety goggles during the experiments are highly recommended. In case of contact between the reagents and the eyes, skin, or clothing, wash immediately with water.

(See the Safety Data Sheet for specific recommendations,
<https://www.kurabo.co.jp/bio/English/>)

◆ Protease EDB

- Do not drink or ingest. Avoid contact with eyes.
- If contact with eyes, skin, or clothing occurs, rinse thoroughly with water. Consult a physician if necessary.

◆ LDB (Lysis Buffer)

- Harmful if ingested.
- Do not drink or ingest. Avoid contact with eyes.
- If contact with eyes, skin, or clothing occurs, rinse thoroughly with water. Consult a physician if necessary.
- Wear a laboratory coat, gloves and safety goggles during experiments.

◆ WDB (Wash Buffer)

- Do not drink or ingest. Avoid contact with eyes.
- If contact with eyes, skin, or clothing occurs, rinse thoroughly with water. Consult a physician if necessary.

◆ CDB (Elution Buffer)

- Do not drink or ingest. Avoid contact with eyes.
- If contact with eyes, skin, or clothing occurs, rinse thoroughly with water. Consult a physician if necessary.

◆ Use or storage of LDB at high temperature should be avoided.

◆ Any solution and waste fluid containing LDB should not be mixed with bleach.

◆ In the case of using potentially infectious samples :

Wear a suitable laboratory coat, disposable gloves and safety goggles during the experiments.

◆ Disposal of waste fluid and consumables when using potentially infectious samples :

After use, dispose of potentially infectious samples and consumables by incineration, high temperature decontamination, sterilization, or disinfection in accordance with applicable laws. When entrusting waste disposal to licensed hazardous waste disposal contractors, use specially controlled waste management forms (manifest), if applicable.

5. Precautions

◆ Handling of Starting Material

- Small amount of samples should be adjusted to 200 µl with PBS (sterilized) before loading.
- Use a whole blood sample treated with EDTA-2Na, EDTA-2K, or heparin.
- Use a whole blood sample within 3 days after collection. The yield of DNA might decrease, or degradation of DNA might be caused when a blood sample preserved for a long time is used.
- The yield of DNA might decrease when the number of leucocytes exceeds 2×10^6 cells/200 µl. In such cases, adjust the number of leucocytes by diluting the sample with PBS (sterilized) to below 2×10^6 cells/200 µl.
- The Cartridge (CA) might clog when the number of leucocytes exceeds 5×10^6 cells/200 µl. We recommend that you dilute the sample with PBS (sterilized) and then perform extraction.

◆ Use of Reagent

- After addition of nuclease-free water to EDB leave it for 30 min or more at room temperature with occasionally stirring. Use it after confirming the powder is completely dissolved. The yield of DNA might decrease or the Cartridge (CA) might clog when dissolution of EDB is insufficient.

◆ Procedure of Extraction

- Use QuickGene DNA whole blood kit S (DB-S) at room temperature (15-30°C). In case of using at lower or higher temperature, it may affect the extraction performance.
- Use a vortex mixer able to stir at 2,500 rpm or more. Weak vortex may cause insufficient dissolution, lead to decrease of the yield of DNA or clogging of the Cartridge (CA).
- During the procedure, work quickly without interruption.
- The yield of DNA varies depending upon sample conditions. The standard yield is 4 to 8 µg from 200 µl whole blood samples.
- We recommend starting preparation of lysate after setup of QuickGene. Refer to the following pages.
- QG-810: 8-3 (p.14), Appendix1 (p.27)
- QG-Mini480: 8-4 (p.17)
- Refer to QuickGene User's Guide for details.

6. Quality Control

- As part of the stringent quality assurance program in KURABO INDUSTRIES LTD., the performance of QuickGene DNA whole blood kit S (DB-S) is evaluated routinely on a lot-to-lot uniformity.
- Yield and quality of extracted genomic DNA are checked by measuring the absorbance at 260 nm, ratio of absorbance (260 nm/280 nm).

7. Product Description

DNA and RNA are included in eluate extracted with this kit. Table 2 shows the average of yield and purity (A260/280) of genomic DNA extracted from 200 µl of whole blood samples.


The yield varies depending upon sample conditions.

Table2

Sample	Amount of genomic DNA (µg)	A260/280
Whole blood (200 µl)	4 - 8	1.97

8. Protocol

[Overview Flow Chart]



8-1. Preparations of Reagents

◆ EDB(Lyophilized)

When using EDB, pipette 3.3 ml of nuclease-free water into the vial containing lyophilized Protease. Dissolve it completely. Reconstituted EDB is stable for 2 months when stored at 4°C.

Storage at -20°C will prolong the life of EDB until 2 months, but repeated freezing and thawing should be avoided. Dividing the solution into aliquots and storage at -20°C is recommended.

Notices Dissolve EDB completely by the following method, and then use the solution. Add 3.3 ml of nuclease-free water, close the cap and mix with inversion the bottle. Leave it for 30 min or more at room temperature with occasionally stirring it. Use it after confirming the powder is completely dissolved. The yield of DNA might decrease or the Cartridge (CA) might clog when dissolution of EDB is insufficient.

◆ LDB(30ml)

Mix thoroughly before using. If the precipitates are contained in Lysis Buffer (LDB), incubate the bottle in a water bath at 37°C and mix with inversion the bottle

intermittently until the precipitates are dissolved. After dissolving the Lysis Buffer (LDB), cool down the bottle to room temperature before using.

◆ CDB(100ml)

Make sure to use CDB for DNA elution.

◆ WDB(160ml)

Provide the concentrated solution. Add 160 ml of >99% ethanol into the bottle and mix with inversion the bottle gently at the beginning of use. After adding of Ethanol, Add 160 ml of >99% ethanol into the bottle and mix by gently inverting the bottle before use. After adding ethanol, enter a check in the [ethanol added?] check box on bottle cap label. Close the cap firmly to prevent volatilizing.

Required volume of WDB (>99% ethanol added) and CDB (In the case of using QG-810)

Prepare the required volume of WDB and CDB into the tubes (see Table 3): set them to Buffer Stand.

Table 3 Necessary volume of WDB and CDB

Number of samples	WDB (QG-810)	CDB (QG-810)
8	26ml	9ml
16	44ml	11ml
24	62ml	13ml
32	80ml	15ml
40	99ml	17ml
48	117ml	19ml
56	135ml	21ml
64	154ml	22ml
72	172ml	24ml

* Required volume of discharge

QG-810: WDB 8.0ml, CDB 7.4ml

Depending on the number of the Cartridges, add WDB and CDB.

Use WDB 2.25 ml and CDB 200 µl per 1 Cartridge.

For example, in case of using 2 Cartridges, 12.5 ml of WDB, 7.8 ml of CDB are required. * Use appropriate tubes according to Table 1 (p.5).

8-2. Lysate Preparation Protocol

QuickGene DNA whole blood kit S (DB-S) corresponds to the extraction of genomic DNA from 200 µl of whole blood sample per each treatment.


【Important notes before starting】

- Cool down all reagents to room temperature before use.
- Set the temperature of a heat block or a water bath to 56°C (it is used in step <3> p.13).
- Follow the volume of samples and buffers described in the workflow (p.12).
- During the procedure, work quickly without interruption.
- To prevent cross-contamination, it is recommended to change the pipette tips between all liquid transfers.
- Any solution and waste fluid containing LDB should not be mixed with bleach.
- When using potentially infectious samples for experiments, dispose them according to the applicable regulations.

【Preparations for starting the experiment】

- WDB is supplied as a concentrate. Check that 160 ml of >99% ethanol is added to WDB before starting an experiment.

Lysate Preparation Workflow



Details of Lysate Preparation Workflow

<1> Follow the protocol of <1a> to <1c> exactly. Do not add LDB directly after addition of EDB to a 1.5 ml microtube. In case the procedure is changed, the yield of DNA may not be obtained.

<1a> Add 30 µl of EDB (previously dissolved in nuclease-free water) to the bottom of a 1.5 ml microtube.

<1b> Add 200 µl of a whole blood sample.

After adding the whole blood, immediately proceed to step <1c>.

Leaving the samples for a long time before addition of LDB might decrease the yield of DNA

<1c> Add 250 µl of LDB, then immediately pipette 5 times.

Instead of pipetting, mixing upside-down 5 times can be performed. In order to ensure efficient lysis, it is essential to mix well the sample and LDB. Pipette (or mix upside-down) surely in order to mix EDB, whole blood sample and LDB efficiently.

<2> Vortex at the maximum speed for 15 sec. Flash spin down for several seconds to remove drops from the inside of the lid.

Surely vortex for 15 sec at the maximum speed. The speed of 2,500 rpm or more is recommended. If you do not have such a vortex mixer, pipette (or mix upside-down) completely at step <1c>.

In case mixing is insufficient, the yield of DNA might decrease or the Cartridge (CA) might clog.

<3> Incubate at 56°C for 2 min.

Prolongation of the incubation time up to 5 min does not affect the yield.

<4> Add 250 µl of >99% ethanol, and vortex at the maximum speed for 15 sec. Flash spin down for several seconds to remove drops from the inside of the lid.

Mix the sample and the ethanol enough. Vortex at the same speed as in step <2>.

Perform the extraction operation quickly after completion of lysis.


8-3 Extraction protocol with QG-810 (p.14)

8-4 Extraction protocol with QG-Mini480 (p.17)

8-3. Extraction Protocol with QG-810

- Please read the User's Guide of QG-810 for the details before using the system.
- Check that 160 ml of >99% ethanol is added to WDB before starting an experiment.
- Select "DNA WHOLE BLOOD" mode as the extraction mode for QG-810.
- All reagents, Cartridges (CA) and tubes are manufactured in clean rooms. Wear gloves during the experiments to avoid nuclease contamination.
- Refer to the User's Guide of QG-810 for the details of setting Cartridges (CA), tubes and each reagent.
- Open the front cover of QG-810 and set the Collection Tubes (CT) and the Waste Tubes (WT) in the Tube Holder (or Collection Tube Holder). Use the specified Cartridges (CA).
- Set WDB (>99% ethanol added) and CDB to QG-810 referring to p.11.
- Incorrect Cartridge (CA) placement may result in the solution spilling or improper extraction.
- Press the [DISCHARGE] button after closed the front cover of QG-810. Because of air in the lines, incorrect volume of reagents may occur without discharge operation.
- Avoid touching the filter in the Cartridge (CA) with the pipette tip.
- Any solution and waste fluid containing LDB should not be mixed with bleach.
- When using potentially infectious samples for experiments, dispose them according to the applicable regulations.

QG-810 Workflow



Details of QG-810 Workflow

<1> <Applying lysate> Carefully transfer the whole lysate (See section 8-2 p.11) to the each Cartridge (CA).

If any aggregates are formed in the lysate, transfer altogether with the aggregates to the Cartridge. Perform the extraction operation quickly after completion of lysate. It is possible to leave it until 30 min if necessary.

<2> <Extraction> Select the appropriate mode for this kit. In case of confirming the setting of parameter, refer to Appendix (p. 27). Close the front cover of QG-810. Confirm the appropriate mode on the operation panel and press the [START] button.

The operation panel shows "PROCESSING" (QG-810) during extracting. In case of using QG-810, extraction progress can be checked by blinking of each lamp (BINDING, WASHING, ELUTION).

Warning Do not open the front cover during the extraction process (while "PROCESSING" or "EXECUTING" is shown on the operation panel). If the front cover is opened, the extraction process will be halted. Confirm it by Table 4.

Table 4 Movement when you opened a front cover during extraction

	QG-810
Extraction process	Stop
Extraction continuation	Impossible*

* See User's Guide of QG-810, "3.5 Operations to Restart Program from Pause" (p.28).

<3> <Extraction completion>

Operation panel displays the extraction results.

Table5 Extraction result

	QG-810	Remarks
Successfully extracted	✓ (Check)	
Extraction failure	— (Hyphen)	Cartridge is clogged
No Cartridge, or No sample	— (Underscore)	No Cartridge or occurrence of error before extraction

Open the front cover and remove the Collection Tubes (CT) from the Tube Holder after QG-810 completely stopped.

The volume of the eluate from each Cartridge will be 200 µl.

The volume of CDB can be reduced to 50 µl, but in that case, elution efficiency might decrease by about 20%.

Refer to Appendix 1 (p.27 for QG-810) to change the volume of CDB.

The standard yield is 4 to 8 µg from 200 µl of whole blood samples.

Cover with the Caps (CAP) on the Collection Tubes (CT) tightly, store at 4°C or –20°C.

In case of storing genomic DNA for a long time, it is recommended to preserve at –20°C.

<4> Remove the Waste Tube (WT) and dispose the waste fluid according to applicable regulations.

Remove the Cartridge Holder and dispose the Cartridges (CA).

Dispose the fluid in the Discharge Tray also.


8-4. Extraction Protocol with QG-Mini480

- Please read the User's Guide of QG-Mini480 for the details before using the system.
- Check that 160 ml of >99% ethanol is added to WDB before starting an experiment.
- Set Waste Tubes (WT) into the Waste Tube Holder of QG-Mini480.
- Set the Collection Tubes into the Collection Tube Holder in order. Cover it using Separator.
- Insert the Cartridge Holder into the correct position of the Waste Tube Holder. Make sure the bulges of Cartridge Holder are inserted into the side notches of the Waste Tube Holder. Keep the Holder Handle of the Collection Tube Holder toward the front side when setting the Collection Tubes.
- Set the Pressure Seal Plate covering the Cartridges. Keep the stainless steel side up, the silicone rubber (Packing) side down and the Packing towards to the Cartridges while setting the Pressure Seal Plate. Check the position of Pressure Seal Plate to make sure the both ends of Pressure Seal Plate are inserted in the notches of Cartridge holder.
- Set the Cartridge Holder and Waste Tube Holder into QuickGene-Mini480, Make sure that the first row of Cartridge/Waste Tube Holder unit is placed at the stopper which located just under the Pressure Head inside the machine the with a gentle push.
- Remove the Cartridge Holder from the Waste Tube Holder, and set it to the correct position of the Collection Tube Holder. Before setting the Cartridge Holder onto the Collection Tube Holder, make sure the Separator is covering on the Collection Tube Holder. Pull out the Separator. (See QuickGene-Mini480 Operation Manual: 2 Operation)
- Avoid touching the filter in the Cartridge (CA) with the pipette tip.
- Any solution and waste fluid containing LDB should not be mixed with bleach.
- When using potentially infectious samples for experiments, dispose of them according to the applicable regulations.

QG-Mini480 Workflow

The pressurization mark "Pressurization" in the workflow indicates the following operations.

1. Set the Cartridge Holder and the Waste Tube Holder in QG-Mini480.
2. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges.
3. Make sure that no liquid remains in the Cartridges (CA) and then return the Rotary Switch to the original position.
4. Set the cartridge holder to the collection tube holder.
5. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges.
6. Pull out the Cartridge Holder and the Collection Tube Holder from QG-Mini480.



Details of QG-Mini480 Workflow

- <1> <Applying lysate> Carefully transfer the whole lysate prepared at 8-2(p.11) to each Cartridge (CA). Set the Pressure Seal Plate covering the Cartridges. Set the Waste Tube Holder with the Cartridge Holder into QuickGene-Mini480. Keep the Holder Handle of the Waste Tube Holder toward the front side when setting Cartridge Holder and Waste Tube Holder into QuickGene-Mini480. Make sure that the first row of Cartridge/Waste Tube Holder unit is placed at the stopper which located just under the Pressure Head inside the machine the with a gentle push. Make sure that no lysate remains in the Cartridges and then return the Rotary Switch to the original position.
- <2> <First wash> Pull out the Cartridge Holder with the Waste Tube Holder and then apply 750 μ l of WDB to the Cartridges (CA). Set the Waste Tube Holder with the Cartridge Holder into QG-Mini480. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges. Make sure that no WDB remains in the Cartridges and then return the Rotary Switch to the original position.
- <3> <Second wash> Pull out the Cartridge Holder with the Waste Tube Holder and then apply 750 μ l of WDB to the Cartridges (CA). Set the Waste Tube Holder with the Cartridge Holder into QG-Mini480. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges. Make sure that no WDB remains in the Cartridges and then return the Rotary Switch to the original position.
- <4> <Third wash> Pull out the Cartridge Holder with the Waste Tube Holder and then apply 750 μ l of WDB to the Cartridges (CA). Set the Waste Tube Holder with the Cartridge Holder into QG-Mini480. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges. Make sure that no WDB remains in the Cartridges and then return the Rotary Switch to the original position.
- <5> <Elution> Make sure the Separator is covering on the Collection Tube Holder. Pull out the Cartridge/Waste Tube Holder, Remove the Cartridge Holder from the Waste Tube Holder, and set it to the correct position of the Collection Tube Holder. Pull out the Separator. Insert the Cartridge Holder into the side notches of the Waste Tube Holder. (See QuickGene-Mini480 Operation Manual:2 Operation) Apply 200 μ l of CDB to the Cartridges (CA) and then set the

Cartridge Holder and the Collection Tube Holder in QG-Mini480. Rotate the Rotary Switch toward the front side to apply air pressure to the Cartridges. Make sure that no CDB remains in the Cartridges and then return the Rotary Switch to the original position.

The standard yield of genomic DNA from 200 μ l of whole blood is 4-8 μ g. If you do not use DNA immediately, please close the tube lid tightly and store at 4°C or -20°C. In case storing genomic DNA for a long time, preserve at -20°C.

9. Troubleshooting

Review the information below to troubleshoot the experiments with QuickGene DNA whole blood kit S (DB-S). (*) : For QG-810
(**) : For QG-Mini480

(1) Low yield or no DNA obtained:

Cause	Action
Inappropriate storage conditions for whole blood sample	Use a whole blood sample within 3 days after collection as much as possible. The yield of DNA might decrease, or degradation of DNA might be caused when a blood sample preserved for a long time is used.
Inadequate dissolution of EDB	After addition of nuclease-free water to EDB leave it for 30 min or more at room temperature with occasionally stirring it. Use it after confirming the powder is completely dissolved.
Insufficient enzymatic activity of EDB	Reconstituted EDB is stable for 2 months when stored at 4°C. Do not use EDB preserved for a longer period than 2 months. Storage at –20°C will prolong the life of EDB, but repeated freezing and thawing should be avoided. Dividing the solution into aliquots and storage at –20°C is recommended.
Inappropriate addition order of reagents and whole blood sample	When preparing lysates, perform the additions to a 1.5 ml microtube in the following order: EDB (previously dissolved in 3.3 ml of nuclease-free water) -> Whole blood sample ->LDB.
Inappropriate volume of whole blood sample	If the volume of a whole blood sample is too much, reduce it to the prescribed volume (200 µl). Small amount of sample should be adjusted to 200 µl with PBS (sterilized) before loading.
Use of too much amount of leucocytes	The yield of DNA might decrease when the number of leucocytes exceeds 2×10^6 cells/200 µl. In such cases, adjust the number of leucocytes by diluting the sample with PBS (sterilized) to below 2×10^6 cells/200 µl.
Insufficient homogenization after addition of LDB	Immediately after addition of LDB, pipette (or mix upside-down), and then vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).
Inappropriate volume of ethanol in lysate	Add the prescribed volume of >99% ethanol.
Insufficient homogenization after addition of ethanol	After addition of ethanol, vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).

Cause	Action
No addition of the prescribed volume of ethanol to WDB	Before using WDB for the first time, ensure that the prescribed volume of >99% ethanol has been added. (See section 8-1 p.9)
Incomplete addition of whole lysate to the Cartridge (CA)	If any aggregates are formed in the lysate, transfer altogether with the aggregates to the Cartridge.
Insufficient volume of CDB (**)	Confirm the amount of CDB is 50 µl or more.
Rupture of filter	Be careful not to allow pipette tip to contact with a filter in the Cartridge (CA).
Perform exceed pressurization (**)	Stop applying air pressure as soon as lysate or WDB is discharged.
Leaving Cartridge (CA) after lysate or WDB are discharged (**)	Stop applying air pressure as soon as lysate or WDB is discharged.
Use of reagents other than CDB to elute genomic DNA	Use CDB to elute genomic DNA.
Use of too old WDB (*)	Check if WDB (>99% ethanol added) set in QG-810 does not pass over 1 day.
DNA degradation	Refer to (3) "DNA degradation".
Inadequate volume of any buffer (*)	Confirm that the set volumes for each buffer to QG-810 are adequate.

(2) Clogging of Cartridge (CA) occurs :

Cause	Action
Use of too much amount of a whole blood sample	Reduce it to the prescribed volume (200 µl).
Use of too much amount of leucocytes	The Cartridge (CA) might clog when the number of leucocytes exceeds 5×10^6 cells/200 µl. The yield of DNA might decrease when the number of leukocytes exceeds 2×10^6 cells/200 µl . In such case, we recommend that you dilute the sample with PBS (sterilized) to below 2×10^6 cells/200 µl, and then perform extraction.

Cause	Action
Insufficient homogenization after addition of LDB	Immediately after addition of LDB, pipette (or mix upside-down), and then vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).
Insufficient homogenization after addition of ethanol	After addition of ethanol, vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).

(3) DNA degradation :

Cause	Action
Inappropriate storage conditions for whole blood sample	Use a whole blood sample within 3 days after collection as much as possible. The yield of DNA might decrease, or degradation of DNA might be caused when a blood sample preserved for a long time is used.

(4) Purity of DNA is low:

Cause	Action
Inappropriate storage conditions for whole blood sample	Use a whole blood sample within 3 days after collection as much as possible. The yield of DNA might decrease, or degradation of DNA might be caused when a blood sample preserved for a long time is used.
Insufficient enzymatic activity of EDB	Reconstituted EDB is stable for 2 months when stored at 4°C. Do not use EDB preserved for a longer period than 2 months. Storage at – 20°C will prolong the life of EDB, but repeated freezing and thawing should be avoided. Dividing the solution into aliquots and storage at – 20°C is recommended.
Inappropriate addition order of reagents and whole blood sample	When preparing lysates, perform the additions to a 1.5 ml microtube in the following order: EDB (previously dissolved in 3.3 ml of nuclease-free water) -> Whole blood sample -> LDB.
Insufficient homogenization after addition of LDB	Immediately after addition of LDB, pipette (or mix upside-down), and then vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).

Cause	Action
Inappropriate volume of ethanol in lysate	Add the prescribed volume of >99% ethanol.
Insufficient homogenization after addition of ethanol	After addition of ethanol, vortex sufficiently (for 15 sec). Perform vortex at the maximum speed (2,500 rpm or more is recommended).
No addition of the prescribed volume of ethanol to WDB	Before using WDB for the first time, ensure that the prescribed volume of >99% ethanol has been added. (See section 8-1 p.9)
Improper washing procedure (**)	Wash 3 times with 750 µl of WDB.
Use of reagents other than CDB to elute genomic DNA	Use CDB to elute genomic DNA.

(5) Subsequent experiments such as PCR etc. do not proceed well :

Cause	Action
Inappropriate amount of DNA is used	Determine the DNA concentration based on the absorbance at 260 nm.
Low purity of DNA	Refer to (4) "Purity of DNA is low".
DNA degradation	Refer to (3) "DNA degradation".

(6) A precipitate is formed in reagents :

Cause	Action
Stored at low temperature	Store buffers at room temperature (15-28°C). If a precipitate is formed, dissolve the precipitate by incubation at 37°C. Cool down it to room temperature before use.

(7) No sample is recovered in Collection Tube (CT) or 1.5 ml microtube (it is vacant) :

Cause	Action
Insufficient set of CDB or no operation of discharging (*)	Set the prescribed volume of CDB according to Table 3 (p.10). In addition, it is necessary to perform a discharging operation according to the User's Guide of QG-810.
Not addition of CDB (**)	After insert the Cartridge Holder to the Elution Position (E), add 200 µl of CDB to Cartridge (CA).
No transfer of the Cartridge Holder to the Elution Position (E) when adding CDB (**)	When adding CDB, addition has to be started after the transfer of the Cartridge Holder to the Elution Position (E).

10. Ordering Information

Product	Cat #
QuickGene DNA tissue kit S For extraction of genomic DNA from tissues	DT-S
QuickGene DNA whole blood kit S For extraction of genomic DNA from whole blood	DB-S
QuickGene RNA tissue kit S II For extraction of total RNA from tissues	RT-S2
QuickGene RNA cultured cell kit S For extraction of total RNA from cultured cells	RC-S
QuickGene RNA cultured cell HC kit S For extraction of total RNA from cultured cells	RC-S2
QuickGene RNA blood cell kit S For extraction of total RNA from leukocytes	RB-S
QuickGene Plasmid kit S II For extraction of plasmid DNA from <i>Escherichia coli</i>	PL-S2

Appendix 1 Setting of QG-810 Parameter

In the case of using QG-810, select "DNA WHOLE BLOOD" mode. The parameter of "DNA WHOLE BLOOD" is the following Table.

Display Sequence	LCD message	PARAMETER
1	BIND PEAK	120
2	WASH COUNT	3
3	WASH PEAK	110
4	WASH VOL1	750
5	WASH VOL2	750
6	WASH VOL3	750
7	WASH VOL4	750
8	WASH VOL5	750
9	WASH DIP TM	0
10	WAS2 WAIT T	0
11	WAS2 COUNT	0
12	WAS2 PEAK	110
13	WASH VOL1	750
14	WASH VOL2	750
15	WASH VOL3	750
16	WASH VOL4	750
17	WASH VOL5	750
18	ELUT VOL	200
19	ELUT PEAK	100
20	ELUT DIP TM	0

* When changing CDB volume to 50 μ l, change "ELUT VOL" to "50".

When changing the parameter, refer to QG-810 User's Guide.

* Trademark and exclusion item

Right to registered name etc. used in this handbook is protected by law especially even in the case of no denotation.



KURABO INDUSTRIES LTD.

Advanced Technology Division, Bio-Medical Department

14-30, Shimokida-Cho, Neyagawa, Osaka 572-0823, Japan

TEL (072) 820-3079 FAX (072) 820-3095

URL; <https://www.kurabo.co.jp/bio/>